




# 800

(Kubota 4i Diesel)

(SN/ 008015- )

## Sweeper Operator Manual



**TennantTrue™ Parts and Supplies**



For the latest Parts manuals and other  
language Operator manuals, visit:

[www.tennantco.com/manuals](http://www.tennantco.com/manuals)

**9013053**

**Rev. 04 (1-2017)**



## INTRODUCTION


This manual is furnished with each new model. It provides necessary operation and maintenance instructions.



**Read this manual completely and understand the machine before operating or servicing it.**

This machine will provide excellent service. However, the best results will be obtained at minimum costs if:

- The machine is operated with reasonable care.
- The machine is maintained regularly - per the machine maintenance instructions provided.
- The machine is maintained with manufacturer supplied or equivalent parts.



### PROTECT THE ENVIRONMENT

Please dispose of packaging materials, used machine components such as batteries and fluids in an environmentally safe way according to local waste disposal regulations.

Always remember to recycle.


### MACHINE DATA

Please fill out at time of installation for future reference.

Model No. - \_\_\_\_\_

Serial No. - \_\_\_\_\_

Installation Date - \_\_\_\_\_



## INTENDED USE

The 800 is an industrial rider machine designed to sweep hard surfaces (concrete, asphalt, stone, synthetic, etc). Typical applications include industrial warehouses, manufacturing facilities, distribution facilities, stadiums, arenas, convention centers, parking facilities, transportation terminals, and construction sites. Do not use this machine on soil, grass, artificial turf, or carpeted surfaces. This machine can be used both indoors and outdoors, but ensure there is adequate ventilation if used indoors. Do not use this machine other than described in this Operator Manual.

### Tennant N.V.

Industrielaan 6 5405 AB

P.O. Box 6 5400 AA Uden- The Netherlands

europa@tennantco.com

www.tennantco.com

Specifications and parts are subject to change without notice.

Original instructions, Copyright © 2014, 2016, 2017 TENNANT Company, Printed in U.S.A.

**CONTENTS**

|                                        | Page |                                        | Page |
|----------------------------------------|------|----------------------------------------|------|
| Safety Precautions .....               | 3    | Maintenance .....                      | 36   |
| Operation .....                        | 7    | Maintenance Chart .....                | 36   |
| Machine Components .....               | 7    | Lubrication .....                      | 39   |
| Controls And Instruments .....         | 8    | Rear Wheel Support .....               | 39   |
| Symbol Definitions .....               | 9    | Front Wheel Bearings .....             | 39   |
| Operation Of Controls .....            | 11   | Side Brush Pivot Pins .....            | 39   |
| Directional Pedal .....                | 11   | Main Brush Adjustment .....            | 39   |
| Brake Pedal .....                      | 11   | Hydraulics .....                       | 40   |
| Parking Brake Pedal .....              | 11   | Hydraulic Fluid Reservoir .....        | 40   |
| Steering Wheel Tilt Handle .....       | 12   | Hydraulic Fluid .....                  | 41   |
| Main Brush Adjustment Knob .....       | 12   | Hydraulic Hoses .....                  | 41   |
| Side Brush Adjustment Knob .....       | 12   | Engine .....                           | 42   |
| Horn Button .....                      | 12   | Engine Oil .....                       | 42   |
| Charging System Light .....            | 13   | Cooling System .....                   | 42   |
| Engine Oil Pressure Light .....        | 13   | Engine Belt .....                      | 43   |
| Engine Water Temperature Light .....   | 13   | Air Conditioning Belt (Option) .....   | 43   |
| Hopper Temperature Light –             |      | Draining Water From The Water /        |      |
| Thermo–Sentry .....                    | 13   | Fuel Separator .....                   | 43   |
| Main Brush Shut Down Light .....       | 14   | Fuel Lines .....                       | 44   |
| Clogged Dust Filter Light .....        | 14   | Priming The Fuel System .....          | 44   |
| Hopper Door Light (Option) .....       | 14   | Fuel Filter .....                      | 44   |
| Glow Plug Light .....                  | 14   | PCV (Positive Crankcase Ventilation)   |      |
| Clogged Hydraulic Filter Light .....   | 15   | Valve .....                            | 44   |
| Fuel Level Gauge .....                 | 15   | Exhaust Manifold .....                 | 44   |
| Hour Meter .....                       | 15   | Turbo Charger .....                    | 45   |
| Operating Lights Switch .....          | 15   | Valve Clearance .....                  | 45   |
| Hazard Light Switch (Option) .....     | 16   | Air Intake Hoses .....                 | 45   |
| Filter Shaker Switch .....             | 16   | Air Filter Indicator .....             | 46   |
| Vacuum Fan Switch .....                | 16   | Air Filter Assembly .....              | 46   |
| Throttle Lever .....                   | 16   | Battery .....                          | 47   |
| Operator Seat .....                    | 17   | Circuit Breakers .....                 | 47   |
| Seat Belts (Option) .....              | 17   | Debris Hopper .....                    | 48   |
| Seat Support .....                     | 17   | Removing Or Replacing The Hopper       |      |
| Windshield Wiper Switch (Option) ..... | 18   | Dust Filter .....                      | 48   |
| Dome Light Switch (Option) .....       | 18   | Cleaning The Hopper Dust Filter .....  | 49   |
| Heater Knob (Option) .....             | 18   | Thermo Sentry .....                    | 49   |
| Fan Speed Switch (Option) .....        | 18   | Main Brush .....                       | 50   |
| Air Conditioning Switch (Option) ..... | 19   | Replacing Or Rotating The Main Brush   | 50   |
| Air Control Vents (Option) .....       | 19   | Checking / Adjusting The Main          |      |
| Brush Information .....                | 20   | Brush Pattern .....                    | 51   |
| How The Machine Works .....            | 20   | Adjusting The Main Brush Width .....   | 52   |
| Pre–Operation Checklist .....          | 21   | Adjusting The Main Brush Taper .....   | 52   |
| Starting The Machine .....             | 22   | Side Brush(es) .....                   | 53   |
| Turning Off The Machine .....          | 23   | Replacing The Side Brush .....         | 53   |
| While Operating The Machine .....      | 24   | Adjusting The Side Brush Pattern ..... | 53   |
| Sweeping .....                         | 25   | Skirts And Seals .....                 | 54   |
| Stop Sweeping .....                    | 26   | Hopper Lip Skirts .....                | 54   |
| Emptying The Hopper .....              | 27   | Hopper Side Skirt .....                | 54   |
| Engaging Hopper Support Bar .....      | 29   | Brush Compartment Skirts .....         | 54   |
| Disengaging Hopper Support Bar .....   | 30   | Rear Skirts .....                      | 54   |
| Options .....                          | 31   | Brush Door Seals .....                 | 55   |
| Vacuum Wand .....                      | 31   | Hopper Dust Seal .....                 | 55   |
| Regenerative Filter System (Rfs) ..... | 34   | Hopper Seals .....                     | 55   |
| Machine Troubleshooting .....          | 35   | Hopper Door Seals .....                | 55   |
|                                        |      | Hopper Vacuum Fan Seal .....           | 56   |
|                                        |      | Hopper Cover Seal .....                | 56   |

|                                       | Page |
|---------------------------------------|------|
| Brakes And Tires .....                | 57   |
| Service Brakes .....                  | 57   |
| Parking Brake .....                   | 57   |
| Tires .....                           | 57   |
| Front / Rear Wheels .....             | 57   |
| Propelling Motor .....                | 58   |
| Air Conditioner Filter (Option) ..... | 58   |
| Pushing, Towing, And Transporting     |      |
| The Machine .....                     | 59   |
| Pushing Or Towing The Machine .....   | 59   |
| Transporting The Machine .....        | 60   |
| Machine Jacking .....                 | 62   |
| Storage Information .....             | 62   |
| Specifications .....                  | 63   |
| General Machine Performance .....     | 64   |
| Power Type .....                      | 64   |
| Steering .....                        | 64   |
| Hydraulic System .....                | 64   |
| Braking System .....                  | 65   |
| Tires .....                           | 65   |
| Machine Dimensions .....              | 65   |

**IMPORTANT SAFETY INSTRUCTIONS – SAVE THESE INSTRUCTIONS**

The following precautions are used throughout this manual as indicated in their description:



**WARNING:** To warn of hazards or unsafe practices that could result in severe personal injury or death.

**FOR SAFETY:** To identify actions that must be followed for safe operation of equipment.

The following information signals potentially dangerous conditions to the operator. Know when these conditions can exist. Locate all safety devices on the machine. Report machine damage or faulty operation immediately.



**WARNING:** Moving belt and fan. Keep away.



**WARNING:** Machine can emit excessive noise. Hearing loss can result. Wear hearing protection.



**WARNING:** Machine emits toxic gases. Serious injury or death can result. Provide adequate ventilation.



**WARNING:** Raised hopper may fall. Engage hopper support bar.



**WARNING:** Lift arm pinch point. Stay clear of hopper lift arms.



**WARNING:** Burn hazard. Hot surface. Do NOT touch.

This machine may be equipped with technology that automatically communicates over the cellular network. If this machine will be operated where cell phone use is restricted because of concerns related to equipment interference, please contact a Tennant representative for information on how to disable the cellular communication functionality.

**FOR SAFETY:**

1. Do not operate machine:
  - Unless trained and authorized.
  - Unless operator manual is read and understood.
  - Under the influence of alcohol or drugs.
  - While using a cell phone or other types of electronic devices.
  - Unless mentally and physically capable of following machine instructions.
  - If it is not in proper operating condition.
  - Without filters in place.
  - In areas where flammable vapors/liquids or combustible dusts are present.
  - In areas that are too dark to safely see the controls or operate the machine unless operating / headlights are turned on.
  - In areas with possible falling objects unless equipped with overhead guard.
2. Before starting machine:
  - Check machine for fluid leaks
  - Keep sparks and open flame away from refueling area.
  - Make sure all safety devices are in place and operate properly.
  - Check brakes and steering for proper operation.
  - Adjust seat and fasten seat belt (if equipped).
3. When starting machine:
  - Keep foot on brake and directional pedal in neutral.

## SAFETY PRECAUTIONS

### 4. When using machine:

- Use only as described in this manual.
- Do not pick up burning or smoking debris, such as cigarettes, matches or hot ashes
- Go slowly on inclines and slippery surfaces.
- Do not sweep on ramp inclines that exceed 15% grade or transport (GVWR) on ramp inclines that exceed 15% grade.
- Use brakes to stop machine.
- Reduce speed when turning.
- Keep all parts of body inside operator station while machine is moving.
- Use care when reversing machine.
- Move machine with care when hopper is raised.
- Do not raise hopper when machine is on an incline.
- Make sure adequate clearance is available before raising hopper.
- Keep children and unauthorized persons away from machine.
- Do not carry passengers on machine.
- Always follow safety and traffic rules.
- Report machine damage or faulty operation immediately.

### 5. Before leaving or servicing machine:

- Do not park near combustible materials, dusts, gases, or liquids.
- Stop on level surface.
- Set parking brake.
- Turn off machine and remove key.

### 6. When servicing machine:

- All work must be done with sufficient lighting and visibility.
- Avoid moving parts. Do not wear loose clothing, jewelry and secure long hair.
- Block machine tires before jacking machine up.
- Jack machine up at designated locations only. Support machine with jack stands.
- Use hoist or jack that will support the weight of the machine.
- Do not power spray or hose off machine near electrical components.
- Disconnect battery connections before working on machine.
- Avoid contact with battery acid.
- Avoid contact with hot engine coolant.
- Do not remove cap from radiator when engine is hot.
- Allow engine to cool.
- Keep flames and sparks away from fuel system service area. Keep area well ventilated.

- Use cardboard to locate leaking hydraulic fluid under pressure.
- All repairs must be performed by a trained service mechanic.
- Do not modify the machine from its original design.
- Use Tennant supplied or approved replacement parts.
- Wear personal protective equipment as needed and where recommended in this manual.



For Safety: wear hearing protection.



For Safety: wear protective gloves.



For Safety: wear eye protection.




For Safety: wear protective dust mask.

### 7. When loading/unloading machine onto/off truck or trailer:

- Empty debris hopper before loading machine.
- Use ramp, truck or trailer that will support the weight of the machine and operator.
- Do not load/unload on ramp inclines that exceed 27% grade.
- Use winch. Do not drive the machine onto/off the truck or trailer unless the load height is 380 mm (15 in) or less from the ground.
- Turn off machine and remove key.
- Set parking brake after machine is loaded.
- Block machine tires.
- Tie machine down to truck or trailer.

The safety labels appear on the machine in the locations indicated. Replace damaged labels.

**WARNING LABEL – Machine emits toxic gases. Serious injury or death can result. Provide adequate ventilation.**




Located on front panel of operator compartment.

**WARNING LABEL – Machine can emit excessive noise. Hearing loss can result. Wear hearing protection.**



Located on front panel of operator compartment.




**FOR SAFETY LABEL – Read manual before operating machine.**



Located on front panel of operator compartment.

**SOUND POWER LABEL**



Located on front panel of operator compartment.

## SAFETY PRECAUTIONS

**WARNING LABEL – Lift arm pinch point. Stay clear of hopper lift arms.**




Located on both hopper lift arms.


**WARNING LABEL – Moving belt and fan. Stay away.**



Located on alternator belt guard, engine top cover, top cover support, and air conditioner belt guard (if machine has air conditioner option).



**WARNING LABEL – Raised hopper may fall. Engage hopper support bar.**



Located on hopper lift arms cross-tube and on both hopper lift arms.

**WARNING LABEL – Burn hazard. Hot surface. Do NOT touch.**




Located on engine side guard.



## OPERATION


### MACHINE COMPONENTS



- A. Operator seat
- B. Air filter assembly
- C. Engine top cover
- D. Engine side cover
- E. Main brush access door

- F. Hopper door
- G. Side brush
- H. Hopper cover
- I. Instrument panel
- J. Steering wheel

## CONTROLS AND INSTRUMENTS



- A. Directional pedal
- B. Brake pedal
- C. Parking Brake Lever
- D. Side Brush Switch
- E. Side Brush Down Pressure Knob
- F. Hopper Door Lever
- G. Hopper Rollout Lever
- H. Hopper Lift Lever
- I. Horn Button
- J. Charging System Light
- K. Engine Oil Pressure Light
- L. Engine Water Temperature Light
- M. Hopper Temperature Light – Thermo Sentry
- N. Main Brush Shut Down Light
- O. Fuel Level Gauge
- P. Hopper Door Light (Option)

- Q. Fuel Level Gauge
- R. Hour Meter
- S. Hazard Light Switch (Option)
- T. Operating Light Switch
- U. Filter Shaker Switch
- V. Vacuum Fan Switch
- W. Ignition switch
- X. Main Brush Switch
- Y. Steering Wheel
- Z. Steering Column Tilt Lever
- AA. Circuit Breakers
- AB. Glow Plugs Light
- AC. Side Brush Switch, Left (Option)
- AD. Heater Knob (Option)
- AE. Clogged Hydraulic Filter Light
- AF. Throttle Lever

**SYMBOL DEFINITIONS**

These symbols identify controls, displays, and features on the machine.



Engine Oil Pressure



Engine Water Temperature



Side Brush Down Pressure Light



Side Brush Down Pressure Heavy



Side Brush Down and On



Side Brush Up and Off



Hopper Door Close



Hopper Door Open



Hopper Roll In



Hopper Roll Out



Hopper Down



Hopper Up



Horn



Charging System



Hopper Temperature – Thermo Sentry



Main Brush Shut Down



Filter Clogged



Hopper Door Closed



Fuel



Hour Meter



Hazard Light



Operating Lights



Fan



Steering Wheel Tilt



Main Brush Down and II Speed



Main Brush Off



Main Brush Down and Normal Speed



Main Brush Down Pressure Light



Main Brush Down Pressure Heavy



Circuit Breaker 1



Circuit Breaker 2



Circuit Breaker 3



Circuit Breaker 4



Circuit Breaker 5



Circuit Breaker 6



Circuit Breaker 7



Circuit Breaker 8



Circuit Breaker 9



Parking Brake



Glow Plugs (Preheat)



Hydraulic Filter Clogged



Diesel fuel only

## OPERATION OF CONTROLS

### DIRECTIONAL PEDAL

Press the top of the *Directional pedal* to move forward and the bottom of the pedal to move backward. The pedal returns to the neutral position when it is released.



### BRAKE PEDAL

Press the *Brake pedal* to stop the machine.



### PARKING BRAKE PEDAL

Pull the parking brake lever up to set the parking brake.



Push the parking brake lever down to release the parking brake.




**NOTE:** If the operator is not in the seat, the parking brake must be engaged or the machine will automatically shut off after 2 seconds.

## OPERATION

### STEERING WHEEL TILT HANDLE

The steering wheel tilt handle controls the angle of the steering wheel.

Adjust: Pull out the tilt handle, move the steering wheel up or down, and release the tilt handle.



### SIDE BRUSH ADJUSTMENT KNOB

The side brush adjustment knob changes the amount of contact the side brush has with the surface being swept. Refer to *ADJUSTING THE SIDE BRUSH PATTERN* section of this manual.



### MAIN BRUSH ADJUSTMENT KNOB

The main brush adjustment knob changes the amount of contact the main brush has with the surface being swept. Refer to *ADJUSTING THE MAIN BRUSH WIDTH* section of this manual.



### HORN BUTTON


The horn button operates the horn.

Sound: Press the button.



## CHARGING SYSTEM LIGHT


The charging system light comes on when the alternator is not operating within normal range; 13.5 to 14.5 V. If the light comes on, stop operating the machine. Contact a TENNANT service representative.



07757

## ENGINE WATER TEMPERATURE LIGHT


The engine water temperature light comes on when the temperature of the engine coolant is more than 113° C (235° F). If the light comes on, stop operating the machine. Contact a TENNANT service representative.



07759

## ENGINE OIL PRESSURE LIGHT

The engine oil pressure light comes on when the engine oil pressure falls below 40 kPa (5 psi). If the light comes on, stop operating the machine. Contact a TENNANT service representative.




07758

## HOPPER TEMPERATURE LIGHT - THERMO-SENTRY

The hopper temperature light comes on when the Thermo-Sentry senses that there is excessive heat in the hopper, possibly from a fire. The Thermo Sentry will stop the vacuum fan.

The Thermo-Sentry has to be reset manually, see *THERMO-SENTRY* in *MAINTENANCE*.




07760

## OPERATION

### MAIN BRUSH SHUT DOWN LIGHT

The main brush shut down light comes on when there is excessive down pressure for the main brush, or there is a problem with the main and side brush hydraulic motor circuit. The brush pressures can be reduced with the main brush and side brush pressure knobs.




07761

### HOPPER DOOR LIGHT (OPTION)

The hopper door light comes on when the hopper door is open.

Make sure the hopper door is closed and the hopper door light is off, before sweeping.




07763

### CLOGGED DUST FILTER LIGHT

The clogged dust filter light comes on when the hopper dust filter is clogged.

To clean the filter, hold the vacuum and filter shaker switch in the **Filter shaker** position. If the clogged dust filter light remains lit, manually clean the hopper dust filter. See *HOPPER DUST FILTER* in the *MAINTENANCE* section of this manual.

**NOTE:** The clogged dust filter light also comes on when the hopper door is closed and the vacuum fan is on.



07762

### GLOW PLUG LIGHT


The glow plug light comes on when the ignition switch is turned counterclockwise to the **Glow plugs** position. The light will go out when the engine is ready to start.





## CLOGGED HYDRAULIC FILTER LIGHT


The clogged hydraulic filter light comes on when the hydraulic filter is clogged. If this light remains on, have the hydraulic filter changed as soon as possible.



## FUEL LEVEL GAUGE

The fuel level gauge indicates how much fuel is in the fuel tank.


**IMPORTANT: Use Low Sulfur Diesel Fuel Only.** DO NOT use other fuels such as Bio-Diesel or add aftermarket additives to the fuel in this machine. Other fuels and aftermarket additives will damage emission components, requiring more frequent and costlier maintenance. Engine damage due to use of other fuels and aftermarket additives may not be covered under the machine warranty.



07764

## HOUR METER

The *Hour meter* records the hours the machine was operated. Use this information to determine machine service intervals.




07765

## OPERATING LIGHTS SWITCH

The operating / hazard lights switch powers on and off the headlights and taillights.

**On:** Press the operating lights switch. The indicator light above the switch will come on.

**Off:** Press the operating lights switch. The indicator light above the switch will go off.



07768


## OPERATION

### HAZARD LIGHT SWITCH (OPTION)

The hazard light switch powers on and off the hazard light.

**On:** Press the hazard light switch. The indicator light above the switch will come on.

**Off:** Press the hazard light switch. The indicator light above the switch will go off.




07766

### VACUUM FAN SWITCH

The vacuum fan switch starts and stops the vacuum fan.

**Start:** Press the vacuum fan switch. The indicator light above the switch will come on.

**Stop:** Press the vacuum fan switch. The indicator light above the switch will go off.



07769


### FILTER SHAKER SWITCH

The filter shaker switch starts the hopper dust filter shaker. The shaker automatically operates for 40 seconds.

**Start:** Press the filter shaker switch. The indicator light will remain on while the filter shaker is operating.

**Stop:** Press the filter shaker switch again **IF** wanting to stop the filter shaker during the 40 second shaking cycle.

**NOTE:** The vacuum fan shuts off while the filter shaker is operating.




07767

### THROTTLE LEVER


The throttle lever controls the engine speed.

**Fast:** Pull the lever into the **Fast** position. This speed is for sweeping.



08456

**Idle:** Push the lever into the **Idle** position. This speed is for idling.




08457

## OPERATOR SEAT


The operator seat has two adjustments. The adjustments are for the front to rear seat position and ride stiffness.

The front-to-back adjustment lever adjusts the seat position.



08443

The ride stiffness is adjusted with the stiffness knob. Turn the knob clockwise to increase the ride stiffness, and counter-clockwise to decrease the ride stiffness.




08444

## SEAT SUPPORT

The *Seat support* holds the seat up to allow access to the fuel lines from the fuel tank.

Lift: Pull up on the seat mounting plate until the seat mount locks up.

Lower: Pull on the release lever and lower the seat mounting plate.



08445

## SEAT BELTS (OPTION)

**FOR SAFETY:** Before starting machine, adjust seat and fasten seat belt (if equipped).



## OPERATION

### WINDSHIELD WIPER SWITCH (OPTION)

The windshield wiper switch operates the windshield wiper on the cab option.

On: Pull out on the switch.

Off: Push in on the switch.




### DOME LIGHT SWITCH (OPTION)

The dome light switch controls the dome light on the cab option.

On: Press on the switch.

Off: Press on the switch again.



### HEATER KNOB (OPTION)

The heater knob controls the cab heater on the cab option. The heater knob is located above the parking brake lever.

On: Pull the knob out until the air temperature is at the desired comfort level. For maximum heat, pull the knob out all the way.

Off: Push the knob in all the way.



### FAN SPEED SWITCH (OPTION)

The fan speed switch controls the speed of the fan in the optional cab. The pressurizer can be set at three different speeds and into the **off** setting. The fan speed switch is located on the roof of the optional cab.

High: Turn the switch clockwise to the **high** setting.

Medium: Turn the switch clockwise to the **medium** setting.

Low: Turn the switch clockwise to the **low** setting.

Off: Turn the switch counter-clockwise to the **off** setting.



### AIR CONDITIONING SWITCH (OPTION)

The air conditioning switch operates the cab's air conditioner in the optional cab. The air conditioning switch is located on the roof of the optional cab.

**On:** Turn the switch clockwise until the air temperature is at the desired comfort level. For maximum cooling, turn the switch clockwise all the way to the maximum position.

**Off:** Turn the switch counter-clockwise all the way to the **off** position.



### AIR CONTROL VENTS (OPTION)

The air control vents control the direction of the air flow in an optional cab. Turn the vents until they meet your desired comfort level. For defrosting, direct the air control vents onto the windows. This creates warm, dry air which works best for defrosting. If this causes the windows to fog, turn on the air conditioner for drier air.



### BRUSH INFORMATION

For best results, use the correct brush type for the cleaning application.

*NOTE: The amount and type of soilage play an important role in determining the type of brushes to use. Contact a Tennant representative for specific recommendations.*

**Polypropylene 8-double Row Main Brush** – Recommended for general sweeping applications.

**Polypropylene and Wire 8-double Row Main Brush** – Recommended for general sweeping and slightly impacted debris.

**Crinkle Wire 8-double Row Main Brush** – Recommended for foundry sweeping where heat may melt synthetic bristles. The stiff wire bristles cut through compacted grime, hard to sweep dirt, and dirt mixed with oil, grease, or mud.

**Nylon 24-row Main Brush** – Recommended for severe dust conditions on rough surfaces. This brush has excellent pickup and long life.

**Nylon Patrol Main Brush** – Recommended for bulky debris swept at faster speeds.

**Heavy Gauge Polypropylene 8-double Row Main Brush** – Recommended for sweeping outdoor areas. The stiffer bristles provide exceptional pickup of heavier bulky debris.

**Polypropylene Side Brush** – Recommended for general sweeping of light to medium debris.

**Nylon Side Brush** – Recommended for general sweeping of rough or irregular surfaces. Nylon has a long wear life.

**Flat Wire Side Brush** – Recommended for outdoor curb-side sweeping where dirt is heavy or compacted.

### HOW THE MACHINE WORKS



The steering wheel controls the direction of machine travel. The directional pedal controls the speed and forward/reverse direction. The brake pedal slows and stops the machine.

The side brush sweeps debris into the path of the main brush. The main brush sweeps debris from the floor into the hopper. The vacuum system pulls dust and air through the hopper and the hopper dust filters.

The side brush sweeps debris into the path of the main brush. The Power Throw brush is used to help pick up bulky debris. The main brush sweeps debris from the floor into the hopper. The vacuum system pulls dust and air through the hopper and the hopper dust filters.

---

**PRE-OPERATION CHECKLIST**

---

- ☐ Check the engine oil level.
- ☐ Check the engine coolant level.
- ☐ Check the windshield washer fluid level (when applicable).
- ☐ Check the radiator and hydraulic cooler fins for debris.
- ☐ Check the hydraulic fluid level
- ☐ Check the machine for fluid leaks.
- ☐ Check the air filter indicator.
- ☐ Check the skirts and seals for damage and wear.
- ☐ Check the condition of the main brush.  
Remove string, banding, plastic wrap, or other debris wrapped around the brush.
- ☐ Side Brush Option: Check the condition of the brush. Remove string, banding, plastic wrap, or other debris wrapped around the brush(es).
- ☐ Side Brush Option: Check the condition of the side brush skirt.
- ☐ Check for rubbing hoses or wires and leaks or obstructions.
- ☐ Check the condition of the hopper dust filter and seals. Clean as required.
- ☐ Check the brakes and steering for proper operation.
- ☐ Check the horn, headlights, taillights, safety lights, and backup alarm (if equipped).
- ☐ Check the fuel level.
- ☐ Empty the debris hopper.
- ☐ Check the service records to determine maintenance requirements.



## OPERATION


### STARTING THE MACHINE

1. Sit in the operator's seat, engage the parking brake, and ensure the directional pedal is in neutral.

**FOR SAFETY: When starting machine, keep foot on brake and directional pedal in neutral.**




2. Move the throttle lever to the **Idle** position.




08457

3. Turn the ignition switch key counterclockwise. The glow plug light will come on. When the glow plug light goes out, the engine is ready to start.



4. Turn the ignition switch key clockwise until the engine starts.

**NOTE:** Do not operate the starter motor for more than 10 seconds at a time or after the engine has started. Allow the starter to cool between starting attempts or damage to the starter motor may occur.



5. Allow the engine and hydraulic system to warm up three to five minutes.


**WARNING:** Machine emits toxic gases. Severe respiratory damage or asphyxiation can result. Provide adequate ventilation. Consult with your regulatory authorities for exposure limits. Keep engine properly tuned.

6. Release the machine parking brake.





7. Move the throttle lever to the **Fast** position.



4. Set the machine parking brake.



8. Turn on lights.
9. Drive the machine to the area to be cleaned.

5. Turn the ignition switch key counterclockwise to turn off the engine. Remove the switch key.




## TURNING OFF THE MACHINE

1. Stop sweeping.
2. Remove foot from the directional pedal. Step on the brake pedal.



3. Move the throttle lever to the **Idle** position.



**FOR SAFETY: Before leaving or servicing machine, do not park near combustible materials, dust, gases, or liquids. Stop on level surface, set parking brake, turn off machine, and remove key.**

### WHILE OPERATING THE MACHINE

---

Pick up oversized debris before sweeping. Pick up wire, string, twine, large pieces of wood, or any other debris that could become wrapped around or tangled in the brushes.

Drive as straight a path as possible. Avoid bumping into posts or scraping the sides of the machine. Overlap the sweep paths by several centimeters (a few inches).

Avoid turning the steering wheel too sharply when the machine is in motion. The machine is very responsive to the movement of the steering wheel. Avoid sudden turns, except in emergencies.

Adjust the machine speed and brush pressure. Use the lowest brush pressure for best performance.

Keep the machine moving to prevent damaging floor finishes.

If poor cleaning performance is observed, stop cleaning and refer to *MACHINE TROUBLESHOOTING* in this manual.

Perform the Daily Maintenance Procedures after each use (see MACHINE MAINTENANCE in this manual).


Drive the machine slowly on inclines. Use the brake pedal to control machine speed on descending inclines. Sweep with the machine up inclines rather than down inclines.

**FOR SAFETY: When using machine, go slowly on inclines and slippery surfaces.**

**FOR SAFETY: When using machine, do not raise hopper when machine is on an incline.**


## SWEEPING

1. Ensure that the hopper is completely lowered.
2. Move the throttle lever to the **Fast** position.




08456

3. The hopper door must be closed during sweeping. If machine is equipped with the hopper door light option, be sure the hopper door light is off. If the hopper door light is on, close the hopper door.




08476


4. Place the main brush switch in the **Normal** or **II Speed** position.



5. Push the top of the side brush switch into the **On/Down** position.



6. Press the vacuum fan switch to start the vacuum.




07769

7. Sweep as needed.

### STOP SWEEPING


1. Push the bottom of the side brush switch into the **Off/Up** position.



2. Place the main brush switch in the middle **Off** position.




3. Press the filter shaker switch to shake the hopper dust filter.



07767

## EMPTYING THE HOPPER

1. Stop sweeping and shake the filter.
2. Slowly drive the machine to the debris site or debris container.
3. Pull and hold the hopper lift lever in the **Up** position to raise the hopper to the desired height.




08480

**FOR SAFETY:** When using machine, do not raise hopper when machine is on an incline. Make sure adequate clearance is available before raising hopper.

**NOTE:** Be aware that the minimum ceiling height needed to high dump the hopper is 3355 mm (11 ft).

4. Release the hopper lift lever up and into the middle (Hold) position.




08481

5. Drive the machine up to the debris container.


**FOR SAFETY:** When using machine, move machine with care if hopper is raised.

6. Pull and hold the hopper rollout lever into the **Out** position.



08477

7. Lower the hopper into the debris container to control dust.
8. Pull and hold the hopper door lever into the **Open** position.




08474

9. Raise the hopper enough and/or close the hopper door to clear the top of the debris container.
10. Slowly back the machine away from the debris site or debris container.

**FOR SAFETY:** When using machine, move machine with care when hopper is raised.


## OPERATION

11. Push and hold the hopper door lever into the **Close** position.




08476

12. Push and hold the hopper rollout lever into the **In** position.



08479

13. Push and hold the hopper lift lever in the **Down** position.



08482

*NOTE: The hopper lift lever, hopper rollout lever, and the hopper door lever can be use together to lift the hopper, rollout the hopper, and open the hopper door.*


## ENGAGING HOPPER SUPPORT BAR

1. Set the machine parking brake.




**FOR SAFETY:** When starting machine, keep foot on brake and directional pedal in neutral.

2. Start the machine.



3. Raise the hopper all the way up.




08480

**FOR SAFETY:** When using machine, make sure adequate clearance is available before raising hopper.

**NOTE:** Be aware that the minimum ceiling height needed to high dump the hopper is 2490 mm (98 in).

4. Remove the support bar from the storage clip.




08589

**WARNING:** Raised hopper may fall. Engage hopper support bar.

5. Lower and position the hopper support bar onto the support bar stop.

6. Slowly lower the hopper so the hopper support bar rests on the support bar stop.



08482

**WARNING:** Lift arm pinch point. Stay clear of hopper lift arms.


7. Turn off the engine.






### DISENGAGING HOPPER SUPPORT BAR

1. Start the machine.




**FOR SAFETY:** When starting machine, keep foot on brake and directional pedal in neutral.

2. Raise the hopper slightly to release the hopper support bar.



08480

3. Put the hopper support bar in the storage clip.




08590



**WARNING:** Lift arm pinch point. Stay clear of hopper lift arms.

4. Lower the hopper.



08482

5. Turn off the engine.





## OPTIONS

### VACUUM WAND


The vacuum wand uses the machine vacuum system. The vacuum hose and wand allow pick-up of debris that is out of reach of the machine.

1. Stop the machine within reach of the area to be vacuumed.
2. Set the machine parking brake.




**NOTE:** If the operator is not in the seat, the parking brake must be engaged or the machine will automatically shut off after 2 seconds.

3. Press the vacuum fan switch to turn off the vacuum fan. The indicator light above the switch will go off.




07769


4. Place the main brush switch into the middle **Off** position to turn off and lift the main brush.



5. Place the bottom of the side brush switch(es) into the **Off/Up** position to turn off and lift the side brush(es).




6. Turn off the engine.
7. Open the forward hopper access door and engage the lift arm.




## OPERATION

8. Remove the vacuum plug from the vacuum adaptor tube in front of the hopper.



9. Remove the vacuum wand and hose from the mounting clips and assemble them together.

10. Connect the vacuum hose to the vacuum adaptor tube in front of the hopper.




11. Slide the vacuum door lever down and to the left into the locked position to close the vacuum door.



12. Start the engine.

13. Press the vacuum fan switch to turn on the vacuum. The indicator light above the switch will go on.




07769

14. Vacuum the area as needed.




**WARNING: Accident may occur. Do not operate vacuum wand while driving.**

15. When done vacuuming, press the vacuum fan switch to turn off the vacuum fan. The indicator light above the switch will go off.




07769


16. Slide the vacuum door lever to the right and up from the locked position to open the vacuum door.




19. Reinstall the vacuum plug into the vacuum adaptor tube in front of the hopper, disengage the lift arm, and close the forward hopper access door.



17. Disconnect the vacuum hose from the vacuum adaptor tube in front of the hopper.



18. Disassemble the vacuum hose assembly and place back onto the hopper in the mounting clips.



### REGENERATIVE FILTER SYSTEM (RFS)

The Regenerative Filter System (RFS) is an option that alternately turns on the filter shaker motors when the filters need cleaning because of a build-up of dust or debris.

Normally the RFS does not require the operator to stop the machine to shake the filters during sweeping operation (except in extreme and severe dust environments). However, it is recommended that the filters are shaken at the operator's initiative each time the hopper is dumped. This can be accomplished during transit to a dump sight. *AVOID* shaking the filters while hopper is in a rolled out position. To initiate a shaking cycle, press the filter button on the instrument panel. See *FILTER SHAKER SWITCH*.

In very severe dust environments, the plugged filter indicator on the instrument panel may remain lit. When this occurs, it is recommended that the operator stop the machine and initiate one or two shake cycles to clear a possible plugged filter condition. After shaking, roll the hopper out to evacuate the dust tray. Resume sweeping operation.

If the hopper is over full, the light may come on. Check the hopper load and dump if necessary.

If the filter light remains on after all the above conditions are corrected, the filters may be plugged or the RFS may be inoperative. Filters may be shaken by the operator initiative by pressing the filter button on the instrument panel if there is a failure in the RFS control system.


Successful operation of the RFS option requires clean, undamaged filters. Plugged filters may cause the RFS to cycle continuously even at start up. The option also requires good sealing of the upper lid to the hopper, as well as a good seal between the two upper filter chambers.

It is recommended that the machine be driven for some test sweeping with the RFS option at initial start up. This next step assumes the hopper cover and upper filter chamber of the hopper was cleaned thoroughly prior to installation of the RFS option. Sweep for 30 minutes and open the hopper cover to check the integrity of the seals. Look at the top of the shaker panels and the underside of the hopper cover. Check for any signs of *dust tracking* that may be caused by a bad seal or filter. Repair as necessary. Perform this check periodically while using the sweeper with the RFS option.

MACHINE TROUBLESHOOTING

| Problem                   | Cause                                                        | Remedy                                             |
|---------------------------|--------------------------------------------------------------|----------------------------------------------------|
| Excessive dusting         | Brush skirts and dust seals worn, damaged, out of adjustment | Replace or adjust brush skirts or dust seals       |
|                           | Hopper dust filter clogged                                   | Shake and/or clean or replace dust filter          |
|                           | Main brush operating in <b>II Speed</b>                      | Operate main brush in <b>Normal</b> speed          |
|                           | Vacuum hose damaged                                          | Replace vacuum hose                                |
|                           | Vacuum fan seal (vacuum fan inlet bracket) damaged           | Replace seal                                       |
|                           | Vacuum fan failure                                           | Contact TENNANT service personnel                  |
|                           | Hopper door partially or completely closed                   | Open the hopper door                               |
|                           | Thermo-Sentry tripped                                        | Reset Thermo Sentry                                |
|                           | Fabric prescreen missing on dust filters                     | Clean filter elements and install fabric prescreen |
| Poor sweeping performance | Brush bristles worn                                          | Replace brushes                                    |
|                           | Main and side brushes not adjusted properly                  | Adjust main and side brushes                       |
|                           | Debris caught in main brush drive mechanism                  | Free drive mechanism of debris                     |
|                           | Main brush drive failure                                     | Contact TENNANT service personnel                  |
|                           | Side brush drive failure                                     | Contact TENNANT service personnel                  |
|                           | Hopper full                                                  | Empty hopper                                       |
|                           | Hopper floor skirts worn or damaged                          | Replace floor skirts                               |
|                           | Hopper door partially or completely open                     | Close the hopper door                              |
|                           | Wrong sweeping brush                                         | Contact TENNANT representative for recommendations |

## MAINTENANCE



### MAINTENANCE CHART

The table below indicates the *Person Responsible* for each procedure.

**O = Operator**

**T = Trained Personnel**

| Interval | Person Resp. | Key | Description                           | Procedure                              | Lubricant/ Fluid | No. of Service Points |
|----------|--------------|-----|---------------------------------------|----------------------------------------|------------------|-----------------------|
| Daily    | O            | 1   | Engine                                | Check oil level                        | EO               | 1                     |
|          |              |     |                                       | Check fan belt for damage and wear     | –                | 1                     |
|          |              |     |                                       | Check coolant level in reservoir       | WG               | 1                     |
|          | O            | 2   | Engine air filter                     | Check indicator                        | –                | 1                     |
|          |              |     |                                       | Empty dust cap                         | –                | 1                     |
|          | O            | 8   | Hydraulic fluid reservoir             | Check fluid level                      | HYDO             | 1                     |
|          | O            | 3   | Brush compartment skirts              | Check for damage, wear, and adjustment | –                | 6                     |
|          | O            | 4   | Hopper lip skirts / Hopper side skirt | Check for damage, wear, and adjustment | –                | 3                     |
|          | O            | 3   | Main brush                            | Check for damage and wear              | –                | 1                     |
|          | O            | 5   | Side brush                            | Check for damage and wear              | –                | 1                     |
|          |              |     |                                       | Check brush pattern                    | –                | 1                     |
|          | O            | 6   | Hopper dust filter                    | Shake                                  | –                | 2                     |

The table below indicates the *Person Responsible* for each procedure.

**O = Operator.**

**T = Trained Personnel.**

| Interval  | Person Resp. | Key | Description                     | Procedure                                          | Lubricant/ Fluid | No. of Service Points |
|-----------|--------------|-----|---------------------------------|----------------------------------------------------|------------------|-----------------------|
| 50 Hours  | O            | 3   | Main brush                      | Rotate end-for-end                                 | –                | 1                     |
|           | T            | 3   | Main brush                      | Check brush pattern. Adjust as necessary           | –                | 1                     |
|           | O            | 6   | Hopper dust filter              | Check / clean                                      | –                | 2                     |
|           | T            | 7   | Main brush adjustment           | Lubricate                                          | SPL              | 1                     |
|           | T            | 1   | Engine                          | Check fuel lines and clamps for wear and leaks     | –                | All                   |
|           |              |     |                                 | Drain water / fuel separator                       | –                | 1                     |
| 100 Hours | T            | 9   | Hydraulic fluid cooler          | Clean cooler fins                                  |                  | 1                     |
|           | T            | 1   | Engine                          | ■ Change oil and oil filter element                | EO               | 1                     |
|           |              |     |                                 | Clean radiator core exterior                       |                  | 1                     |
|           | O            | 10  | Tires                           | Check pressure                                     | –                | 3                     |
|           | O            | 3   | Main brush and hopper seals     | Check for damage or wear                           | –                | 12                    |
|           | T            | 1   | Air conditioner belt (option)   | Check tension                                      | –                | 1                     |
|           | T            | –   | Air conditioner filter (option) | Clean, or replace if necessary                     | –                | 1                     |
| 200 Hours | T            | 1   | Engine                          | Steam clean exterior                               | –                | 1                     |
|           | T            | 11  | Rear wheel support bearings     | Lubricate                                          | SPL              | 2                     |
|           | T            | 12  | Parking brake                   | Check adjustment                                   | –                | 1                     |
|           | T            | 13  | Side brush pivot pins           | Lubricate                                          | SPL              | 1                     |
| 250 Hours | T            | 1   | Engine                          | Check radiator hoses and clamps for wear and leaks | –                | All                   |
|           |              |     |                                 | Check fan belt adjustment                          | –                | 1                     |
|           |              |     |                                 | Check air intake hoses                             | –                | 1                     |
|           | T            | 2   | Engine air filter               | Clean air filter element                           | –                | 1                     |
| 400 Hours | T            | 14  | Brake master cylinder           | Check fluid level                                  | BF               | 1                     |
|           | T            | 1   | Engine                          | Flush radiator and replace coolant                 | –                | 1                     |

#### LUBRICANT/FLUID

BF . . . . Brake fluid.

EO . . . . SAE 10W–30 Engine oil, API diesel classification CJ–4 or better, CF / SH.

HYDO . **TennantTrue** premium hydraulic fluid or equivalent

SPL . . . Special lubricant, Lubriplate EMB grease (TENNANT part no. 01433–1)

WG . . . Water and ethylene glycol anti-freeze, –34° C (–30° F)

*NOTE: More frequent intervals may be required in extremely dusty conditions.*

*NOTE: Check procedures indicted (■) after the first 50-hours of operation.*

## MAINTENANCE

The table below indicates the *Person Responsible* for each procedure.

**O = Operator.**

**T = Trained Personnel.**

| Interval   | Person Resp. | Key | Description               | Procedure                                        | Lubricant/ Fluid | No. of Service Points |
|------------|--------------|-----|---------------------------|--------------------------------------------------|------------------|-----------------------|
| 500 Hours  | T            | 1   | Engine                    | Replace fuel filter                              | –                | 1                     |
|            |              |     |                           | Replace fan belt                                 | –                | 1                     |
|            |              |     |                           | Clean dust from grill and radiator fins          | –                | 1                     |
| 800 Hours  | T            | 8   | Hydraulic reservoir       | Replace filler cap                               | –                |                       |
|            | T            | –   | Hydraulic hoses           | Check for wear and damage                        | –                | All                   |
|            | T            | 11  | Propelling motor          | ■ Torque shaft nut                               | –                | 1                     |
|            | T            | 11  | Front / rear wheels       | ■ Torque wheel nuts                              | –                | 1                     |
|            | T            | 15  | Battery                   | ■ Clean and tighten battery cable connections    | –                | 1                     |
| 1000 Hours | T            | 1   | Engine                    | Check valve clearance                            | –                | 4                     |
| 1200 Hours | T            | 16  | Hydraulic fluid filter    | Change filter element                            | –                | 1                     |
| 1500 Hours | T            | 1   | Engine                    | Check PCV (Positive Crankcase Ventilation) valve | –                | 1                     |
| 1600 Hours | T            | 17  | Front wheel bearings      | Check, lubricate, and adjust                     | SPL              | 2                     |
| 2400 Hours | T            | 8   | Hydraulic fluid reservoir | Replace suction strainer                         | –                | 1                     |
|            |              |     |                           | Change hydraulic fluid                           | HYDO             | 1                     |
| 3000 Hours | T            | 1   | Engine                    | Check turbocharger for leaks                     | –                | 1                     |
| 1 Year     | T            | 1   | Engine                    | Check exhaust manifold for damage / leaks        | –                | 1                     |
|            | T            | 2   | Engine air filter         | Replace air filter element                       | –                | 1                     |
| 2 Years    | T            | 1   | Engine                    | Replace turbo sensor pressure hose               | –                | 1                     |
|            |              |     |                           | Replace turbo charger lubricant hose             | –                | 1                     |
|            |              |     |                           | Replace fuel hoses and clamps                    | –                | All                   |
|            |              |     |                           | Replace air intake hoses                         | –                | All                   |
|            |              |     |                           | Replace cooling system hoses and clamps          | –                | All                   |

### LUBRICANT/FLUID

BF . . . . Brake fluid.

EO . . . . SAE 10W–30 Engine oil, API diesel classification CJ–4 or better, CF / SH.

HYDO . **TennantTrue** premium hydraulic fluid or equivalent

SPL . . . Special lubricant, Lubriplate EMB grease (TENNANT part no. 01433–1)

WG . . . Water and ethylene glycol anti-freeze, –34° C (–30° F)

*NOTE: More frequent intervals may be required in extremely dusty conditions.*

*NOTE: Check procedures indicted (■) after the first 50-hours of operation.*




## LUBRICATION

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

### REAR WHEEL SUPPORT


Lubricate the rear wheel support bearing after every 200 hours of operation.



08451

### FRONT WHEEL BEARINGS


Repack and adjust the front wheel bearings after every 1600 hours of operation.



08579

### SIDE BRUSH PIVOT PINS


Lubricate the side brush pivot pins after every 200 hours of operation.



08581

### MAIN BRUSH ADJUSTMENT

Lubricate the main brush adjustment after every 50 hours of operation.



08934


## HYDRAULICS

**FOR SAFETY: Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.**


### HYDRAULIC FLUID RESERVOIR

The hydraulic fluid reservoir is located behind the operator seat.

Check the hydraulic fluid level at operating temperature daily. Make sure the hopper is down when checking hydraulic fluid level. The sight gauge is marked with FULL (black line) and ADD (red line) levels to indicate the level of hydraulic fluid in the reservoir.



A filler cap with a built-in breather is mounted on top of the hydraulic reservoir. Replace the cap every 800 hours of operation.




Lubricate the filler cap gasket with a film of hydraulic fluid before putting the cap back on the reservoir.

**ATTENTION! Do not overfill the hydraulic fluid reservoir or operate the machine with a low level of hydraulic fluid in the reservoir. Damage to the machine hydraulic system may result.**

Drain and refill the hydraulic fluid reservoir with new **TennantTrue** premium hydraulic fluid after every 2400 hours of operation.

The reservoir has a built-in strainer outlet that filters hydraulic fluid before it enters the system. Replace the strainer after every 2400 hours of operation.

The hydraulic fluid filter is located in the engine compartment. Replace the filter element after every 1200 hours of operation or if the clogged hydraulic filter light remains on. Check the hydraulic fluid level and refill as needed.



## HYDRAULIC FLUID

There are three fluids available for different temperature ranges:

| Tennant <i>True</i> premium hydraulic fluid (Extended Life) |                  |                                |                                |
|-------------------------------------------------------------|------------------|--------------------------------|--------------------------------|
| Part Number                                                 | Capacity         | ISO Grade Viscosity Index (VI) | Ambient Air Temperature Ranges |
| 1057710                                                     | 3.8 L<br>(1 gal) | ISO 100<br>VI 126 or higher    | 29° C<br>(85° F) or higher     |
| 1057711                                                     | 19 L<br>(5 gal)  |                                |                                |
| 1057707                                                     | 3.8 L<br>(1 gal) | ISO 32<br>VI 163 or higher     | 7° C<br>(45° F) or lower       |
| 1057708                                                     | 19 L<br>(5 gal)  |                                |                                |

If using a locally-available hydraulic fluid, be sure the specifications match the Tennant hydraulic fluid specifications. Substitute fluids can cause premature failure of hydraulic components.


**ATTENTION!** Hydraulic components depend on system hydraulic fluid for internal lubrication. Malfunctions, accelerated wear, and damage will result if dirt or other contaminants enter the hydraulic system.

## HYDRAULIC HOSES

Check the hydraulic hoses after every 800 hours of operation for wear or damage.

**FOR SAFETY:** When servicing machine, use cardboard to locate leaking hydraulic fluid under pressure.

High pressure fluid escaping from a very small hole can almost be invisible, and can cause injury.



00002

Contact appropriate personnel if a leak is discovered.


**ATTENTION:** Only use TENNANT supplied hydraulic hoses or equivalent rated hydraulic hoses.

## ENGINE

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

### ENGINE OIL

Check the engine oil level daily. Change the engine oil and oil filter after the first 50 hours of machine operation, and then after every 100 hours of operation.




The engine oil drain is located on the engine oil pan. Drain the engine oil when it is warm.

Fill the engine with oil until the oil is between the indicator marks on the dipstick. DO NOT fill past the top indicator mark. The engine oil capacity is 5.7 L (6 qt) including the oil filter.


### COOLING SYSTEM

**FOR SAFETY:** When servicing machine, avoid contact with hot engine coolant. Do not remove cap from radiator when engine is hot. Allow engine to cool.


Check the coolant level in the reservoir daily. The coolant level must be between the two indicator marks when the engine is cold. Refer to the coolant manufacturer for water/coolant mixing instructions.



Check the radiator hoses and clamps after every 250 hours of operation. Tighten loose clamps. Replace damaged hoses and clamps.



Check the radiator core exterior and hydraulic cooler fins after every 100 hours of operation. Blow or rinse (with low pressure air or water) all dust through the grill and radiator fins, the opposite direction of normal air flow after every 500 hours of operation. Be careful to not bend the cooling fins when cleaning. Clean thoroughly to prevent the fins from becoming encrusted with dust. To avoid cracking the radiator, allow the radiator and cooler fins to cool before cleaning.




08454

Flush the radiator and the cooling system after every 400 hours of operation.

Replace the radiator hoses and clamps every two years.

## ENGINE BELT

Check the the engine fan belt for wear and damage daily. Check the engine belt tension after 250 hours of operation. Adjust tension as necessary. Proper belt tension is 7 to 9 mm (0.28 to 0.35 in) from a force of 10 kg (22 lb) applied at the mid-point of the longest span.




08935

Replace the engine fan belt after every 500 hours of operation.

## AIR CONDITIONING BELT (OPTION)

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

Check the engine belt tension after every 100 hours of operation. Adjust the tension as necessary. Proper belt tension is 4 to 7 mm (0.025 to 0.25 in) from a force of 25 to 27 kg (55 to 60 lb) applied at belt midpoint.




## DRAINING WATER FROM THE WATER / FUEL SEPARATOR

**FOR SAFETY:** When servicing machine, keep flames and sparks away from fuel system service area. Keep area well ventilated.

Drain water from the water / fuel separator after every 50 hours of operation.

Turn the key to the on position without starting the engine.

Turn the water / fuel separator fitting located on the top of the filter bracket to and wait for fuel to drain from the fitting.



Close the water / fuel separator fitting after a steady stream of fuel begins to drain.



### FUEL LINES

Check the fuel lines after every 50 hours of operation. If a clamp band is loose, apply oil to the screw of the band and securely tighten the band.

The rubber fuel lines can become worn-out whether the engine has been used much or not. Replace the fuel lines and clamp bands every two years.

**FOR SAFETY: When servicing machine, keep flames and sparks away from fuel system service area. Keep area well ventilated.**



If the fuel lines and clamp bands are found worn or damaged before two years; replace or repair them at once. Bleed the fuel system after replacing any fuel lines and / or the fuel filter, see PRIMING THE FUEL SYSTEM. When the fuel lines are not installed, plug both ends with clean cloth or paper to prevent dirt from entering the lines. Dirt in the lines can cause a fuel injection pump malfunction.

### PRIMING THE FUEL SYSTEM

Typical diesel fuel systems require priming to remove pockets of air from the fuel lines and fuel components. This is usually required after running out of fuel, changing fuel filter elements or repairing a fuel system component. Air in the fuel prevents smooth engine operation. Refer to the engine manufacturer's manual for additional information.


### FUEL FILTER

Replace both fuel filters after every 500 hours of operation.



### PCV (POSITIVE CRANKCASE VENTILATION) VALVE

Check the PCV after every 1500 hours of operation.




### EXHAUST MANIFOLD


Check the exhaust manifold for damage and leaks yearly.

## TURBO CHARGER


Check the turbo charger for leaks after every 3000 hours of operation.



Replace the turbo charger sensor pressure hose every two years.



Replace the turbo charger lubricant hose every two years.




## VALVE CLEARANCE

Check and adjust the valve clearance to 0.18 to 0.22 mm (0.0071 to 0.0086 in) while the engine is cold after every 1000 hours of operation.

## AIR INTAKE HOSES

Check the air intake hoses leaks and damage after every 250 hours of operation.



Replace the air intake hoses every two years.



## MAINTENANCE

### AIR FILTER INDICATOR

Check the indicator daily. The indicator red line will move as the air filter element fills with dirt. Do not replace the air filter element until the red line reaches 5 kPa (20 in H<sub>2</sub>O) and the "SERVICE WHEN RED" window is filled with red. The engine must be running to get an accurate air indicator reading.

**FOR SAFETY:** When servicing machine, avoid moving parts. Do not wear loose clothing, jewelry, and secure long hair.



### AIR FILTER ASSEMBLY

Empty the engine air filter dust cap daily.

Clean the air filter element after every 250 hours of operation. Replace the air filter element yearly.

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.


Replace the air filter element when the air filter indicator shows restriction in the air intake system or the filter element is damaged. Refer to *AIR FILTER INDICATOR*.




Remove the filter element. Carefully clean the end cap and the interior of the housing with a damp cloth. Clean the housing sealing surfaces.



Install the filter element into the air filter housing and reinstall the dust cap with the water drain pointing down.



Push the reset button on the end of the indicator to reset the air filter indicator after replacing the air filter element.






## BATTERY

Clean and tighten the battery connections after the first 50 hours of operation and after every 800 hours after that. Do not remove the vent plugs from the battery or add water to the battery.

Remove the engine compartment access panel located in the operator compartment to access the battery.



**FOR SAFETY:** When servicing machine, avoid contact with battery acid.

## CIRCUIT BREAKERS

Circuit breakers are resettable electrical circuit protection devices designed to stop the flow of current in the event of a circuit overload. Once a circuit breaker is tripped, it must be reset manually. Press the reset button after the breaker has cooled down.



If the overload that caused the circuit breaker to trip is still there, the circuit breaker will continue to stop current flow until the problem is corrected.

All but two of the circuit breakers are located in the operator compartment. There are two 30 Amp circuit breakers located behind the circuit breaker panel that can be accessed by raising the hopper. The self-resetting 30 Amp circuit breakers will reset themselves after cooling down.

Refer to the table below for the *circuit breakers* and the circuits protected.

| Circuit Breaker | Rating | Circuit Protected      |
|-----------------|--------|------------------------|
| CB-1            | 15 A   | Horn                   |
| CB-2            | 15 A   | Filter shaker          |
| CB-3            | 15 A   | Controls               |
| CB-4            | 15 A   | Instrument panel       |
| CB-5            | 15 A   | Hazard light           |
| CB-6            | 2.5 A  | Brushes                |
| CB-7            | 15 A   | Left side brush option |
| CB-8            | 15 A   | Cab accessories        |
| CB-9            | 15 A   | Accessories            |
| CB-10           | 30 A   | AC compressor/blower   |
| CB-11           | 30 A   | AC condenser/fans      |

## DEBRIS HOPPER

The dust filters filter the air pulled up from the hopper. The dust filters are equipped with a shaker to remove the accumulated dust particles. The dust filters shaker is operated by the filter shaker switch.

Shake the dust filters before dumping the hopper and at the end of every work shift. Avoid shaking the filters while the hopper is in a rolled out position. Check and clean the dust filters every 50 hours of operation. Extremely dusty conditions may require more frequent cleaning of dust filters. Replace damaged dust filters.


### REMOVING OR REPLACING THE HOPPER DUST FILTER

**NOTE:** Clean the filter more often if used in extremely dusty conditions.

1. Shake the hopper dust filter.
2. Stop the engine and set the machine parking brake.

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.


3. Open the hopper cover.
4. Disconnect the shaker motor wire connectors.
5. Remove the four retaining screws from the filter shaker frame.



08591


6. Pull the filter shaker frame out of the hopper.
7. Carefully turn over the shaker frame and element.

8. Loosen the four filter retaining screws from the shaker frame.



08592

9. Remove the retainer ring from the shaker frame. Remove the filter.
10. Make sure the prescreen wrap is tightly wrapped around and securely fastened on the new filter element. Put the new filter on the filter shaker frame.
11. Place the retainer ring over the filter. Make sure the retaining ring fits inside the lip of the filter element all the way around. Line up the slots on the retainer ring with the retaining screws holes.




08593

12. Mount using the retaining screws.
13. Check the seal on the shaker frame for damage. Make sure the vibration isolators are mounted in all four corners of the filter shaker frame.
14. Put the filter and shaker frame in the hopper.
15. Install the four retaining screws and tighten.
16. Connect the shaker motor wire connectors.

## CLEANING THE HOPPER DUST FILTER

To clean the dust filters, use one of the following methods:

- **SHAKING** – Press the filter shaker switch.
- **AIR** – Blow compressed air through the dust filter from the inside. This may be done with the dust filter in the machine, or for more efficient cleaning remove the dust filter from the machine and the prescreen wrap from the filter element.




08594

- **WATER** – Remove the fabric prescreen wrap from the filter element. Wash the prescreen wrap in a water and mild detergent solution. Rinse the prescreen wrap until it is clean. Air dry the wet prescreen wrap; do not use compressed air. **NEVER** wash the filter element with water.

## THERMO SENTRY

The Thermo Sentry senses the temperature of the air pulled up from the hopper. If there is a fire in the hopper, the Thermo Sentry stops the vacuum fan and cuts off the air flow. The Thermo Sentry is located on the vacuum fan housing.

Press the reset button to reset the Thermo Sentry.



08928

### MAIN BRUSH

Check the brush daily for wear or damage. Remove any string or wire tangled on the main brush, main brush drive hub, or main brush idler hub.



Check the main brush pattern and rotate the brush end-for-end after every 50 hours of operation, for maximum brush life and best sweeping performance. Refer to *REPLACING OR ROTATING THE MAIN BRUSH*.


Replace the brush when it no longer cleans effectively.

### REPLACING OR ROTATING THE MAIN BRUSH

1. Raise the main brush.
2. Turn off the machine and set the machine parking brake.


**FOR SAFETY: Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.**

3. Open the right side main brush access door.
4. Unlatch and remove the brush idler plate.




08487

5. Grasp the main brush; pull it off the brush drive plug and out of the main brush compartment.



08488

6. Put the new or rotated end-for-end main brush on the floor next to the access door.
7. Slide the main brush onto the drive plug. Rotate the brush until it engages the drive plug, and push it all the way onto the plug.
8. Slide the main brush idler plate plug onto the main brush.
9. Latch the idler plate onto the machine frame.



08489

10. Close the right side main brush access door.
11. Check and adjust the brush pattern if needed after rotating them. Refer to *CHECKING THE MAIN BRUSH PATTERN*.

## CHECKING / ADJUSTING THE MAIN BRUSH PATTERN

1. Apply chalk, or a similar marking material, to a smooth and level section of the floor.
2. Raise the side brush and main brush and position the main brush over the chalked area.


*NOTE: If chalk or other material is not available, allow the brush to spin on the floor for two minutes. A polish mark will remain on the floor.*

3. Start the main brush.
4. Lower the main brush for 15 to 20 seconds while keeping a foot on the brakes to keep the machine from moving. This will lower the rotating main brush.
5. Raise the main brush.
6. Stop the main brush.
7. Drive the machine off the test area.


**FOR SAFETY: Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.**

8. Observe the width of the brush pattern. The brush pattern should be 65 to 75 mm (2.5 to 3.5 in) across the entire length of the brush. Refer to *ADJUSTING THE MAIN BRUSH WIDTH*.

9. Observe the brush taper. If the brush pattern is tapered, see *ADJUSTING THE MAIN BRUSH TAPER* section of this manual.



00601




00582

## MAINTENANCE


### ADJUSTING THE MAIN BRUSH WIDTH

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

1. Observe the width of the brush pattern.
2. To increase the width of the main brush pattern, turn the main brush down pressure knob counter-clockwise.




To decrease the width of the main brush pattern, turn the main brush down pressure knob clockwise.



### ADJUSTING THE MAIN BRUSH TAPER


**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

1. Observe the brush taper.
2. Loosen the brush drive end plate mounting bolts.



08450

3. Turn the taper adjustment nut counter-clockwise to increase the pattern width at the brush drive end, and clockwise to decrease the pattern width at the brush drive end. Tighten the drive end plate mounting bolts.



08490

4. Check the main brush pattern and readjust as necessary. Then adjust the width of the main brush pattern.



## SIDE BRUSH(ES)

Check the brush(es) daily for wear or damage. Remove any string or wire found tangled in the brush(es) or drive hub(s).


Replace the brush(es) when it no longer cleans effectively.

## REPLACING THE SIDE BRUSH

1. Empty the debris hopper.
2. Set the machine parking brake.
3. Raise the hopper.
4. Turn off the engine.

**FOR SAFETY: Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.**

5. Remove the side brush retaining pin from the side brush drive shaft.



08466


6. Slide the side brush off the side brush drive shaft.

**NOTE:** Remove the drive hub and put it on the new brush if one is not installed.

7. Slide the new side brush onto the side brush drive shaft.
8. Insert the side brush retaining pin through the side brush hub and shaft and secure.
9. Disengage the hopper support bar and lower the hopper.
10. Adjust the side brush pattern with the side brush down pressure knob.

## ADJUSTING THE SIDE BRUSH PATTERN

Check the side brush pattern daily. The side brush bristles should touch the floor in the patterns shown in the illustration.



350327

Turn the knob counterclockwise to increase the brush pressure and clockwise to decrease the brush pressure.



## SKIRTS AND SEALS


**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

### HOPPER LIP SKIRTS

The hopper lip skirts are located on the bottom rear of the hopper. The skirts float over debris and help deflect that debris into the hopper. The top skirt is segmented.

Check the hopper lip skirts for wear or damage daily.


Replace the hopper lip skirts when they no longer touch the floor.



### HOPPER SIDE SKIRT

The hopper side skirt is located on the left side of the hopper.

Check the hopper side skirt for wear or damage and adjustment daily.




## BRUSH COMPARTMENT SKIRTS

The brush compartment skirts are located on the bottom of each of the two main brush doors and around the ends of the brush on the main frame. The inside brush door skirt should touch the floor, and the outside brush door skirt should clear the floor by 3 to 5 mm (0.12 to 0.25 in).

Check the skirts for wear or damage and adjustment daily.

*NOTE: The brush door skirts have slotted holes to allow for a ground clearance adjustment. The door must be closed for proper adjustment.*

*NOTE: Tire pressure will affect skirt clearances.*




## REAR SKIRTS

The two rear skirts are located on the bottom rear of the main brush compartment. The vertical skirt should clear the floor up to 20 mm (0.75 in) in dusty conditions, and touch the floor otherwise. The recirculation skirt is self-adjusting.

Check the skirts for wear or damage and adjustment daily.

*NOTE: Tire pressure will affect skirt clearances.*






## BRUSH DOOR SEALS

The brush door seals are located on both main brush doors and on corresponding portions of the main frame.

Check the seals for wear or damage after every 100 hours of operation.




08495

## HOPPER SEALS

The hopper seals are located on the top and side portions of the machine frame that contact the hopper.

Check the seals for wear or damage after every 100 hours of operation.




08496

## HOPPER DUST SEAL

The hopper dust seal is located inside the hopper. It seals the hopper filter compartment.

Check the seal for wear or damage after every 100 hours of operation.




08498

## HOPPER DOOR SEALS

The hopper door seals are located on the hopper door. They seal the hopper when the hopper door is closed.

Check the seals for wear or damage after every 100 hours of operation.




08497

### HOPPER VACUUM FAN SEAL

The hopper vacuum fan seal is mounted on the the vacuum fan inlet bracket.


Check the seal for wear or damage after every 100 hours of operation.



### HOPPER COVER SEAL

The hopper cover seals are located on the inside of the hopper cover. They seal the hopper filter compartment.

Check the seal for wear or damage after every 100 hours of operation.



## BRAKES AND TIRES


### SERVICE BRAKES

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.

The hydraulic service brakes are located on the front wheels.

The master brake cylinder is located on the fire wall.

Check the master brake cylinder fluid level after every 400 hours of operation.



08501

### PARKING BRAKE

**FOR SAFETY:** Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.


Adjust the parking brake whenever it becomes very easy to set, when the machine rolls after setting it, and after every 200 hours of operation.



### TIRES

The standard machine tires are pneumatic.

Check the tire pressure after every 100 hours of operation. The proper tire air pressure is 690 – 758 kPa (100 – 110 psi).




08575

### FRONT / REAR WHEELS

Torque the front wheel nuts twice in the pattern shown to 169 to 183 Nm (125 to 135 ft lb) after the first 50-hours of operation, and after every 800 hours of operation.

Torque the rear wheel nuts twice in the pattern shown to 122 to 155 Nm (90 to 110 ft lb) after the first 50 hours of operation, and after every 800 hours of operation.



## MAINTENANCE


### PROPELLING MOTOR

Torque the shaft nut to 270 Nm (200 ft lb) after the first 50 hours of operation and after every 800 hours thereafter.



### AIR CONDITIONER FILTER (OPTION)

Clean the air conditioner filter after every 100 hours of operation. Replace the air conditioner filter if it is damaged.




## PUSHING, TOWING, AND TRANSPORTING THE MACHINE

### PUSHING OR TOWING THE MACHINE

If the machine becomes disabled, it can be pushed from the front or rear, but only towed from the rear.


The propelling pump has a bypass valve to prevent damage to the hydraulic system when the machine is being pushed or towed. This valve allows a disabled machine to be moved for a *very short distance* and at a speed to not exceed 1.6 kp/h (1 mph). The machine is NOT intended to be pushed or towed a long distance or at a high speed.



08576

**ATTENTION! Do not push or tow machine for a long distance and without using the bypass valve, or the machine hydraulic system may be damaged.**

Turn the bypass valve 90° from the normal position before pushing or towing the machine. **The illustration shows the bypass valve in the pushing or towing position.**



Return the bypass valve to the normal position when through pushing or towing the machine.

## MAINTENANCE


### TRANSPORTING THE MACHINE

1. Position the machine at the loading edge of the truck or trailer.

**FOR SAFETY:** When loading/unloading machine onto/off truck or trailer, empty debris hopper before loading machine.


2. If the loading surface is not horizontal or is higher than 380 mm (15 in) from the ground, use a winch to load machine.

If the loading surface is horizontal AND is 380 mm (15 in) or less from the ground, the machine may be driven onto the truck or trailer.




**FOR SAFETY:** When loading machine onto truck or trailer, use winch. Do not drive the machine onto the truck or trailer unless the loading surface is horizontal AND is 380 mm (15 in) or less from the ground.


3. To winch the machine onto the truck or trailer, attach the winching chains to the rear tie down locations.



The rear tie-down locations are through the U-bolt section of the main frame under the side bumpers toward the rear.




4. Turn the bypass valve 90° from the normal position before winching the machine onto the truck or trailer. See *PUSHING OR TOWING THE MACHINE* section of this manual. Make sure the machine is centered.




08576

5. Position the machine onto the truck or trailer as far as possible. If the machine starts to veer off the center line of the truck or trailer, stop and turn the steering wheel to center the machine.
6. Set the parking brake and block the machine tires. Tie down the machine to the truck or trailer before transporting.

The two front tie-down locations are through the U-bolt section of the main frame in front of the wheels.



The two rear tie-down locations are through the U-bolt section of the main frame under the side bumpers toward the rear.



7. If the loading surface is not horizontal or is higher than 380 mm (15 in) from the ground, use a winch to unload machine.

If the loading surface is horizontal AND is 380 mm (15 in) or less from the ground, the machine may be driven off the truck or trailer.

**FOR SAFETY: When unloading machine off truck or trailer, use winch. Do not drive the machine off the truck or trailer unless the loading surface is horizontal AND is 380 mm (15 in) or less from the ground.**

8. Return the bypass valve to the normal position when through loading the machine. Refer to *PUSHING OR TOWING THE MACHINE* section of this manual.


### MACHINE JACKING

Empty the hopper before jacking up the machine. Jack up the machine at the designated locations. Use a hoist or jack capable of supporting the weight of the machine. Use jack stands to support the machine.

**FOR SAFETY: Before leaving or servicing machine, stop on level surface, set parking brake, turn off machine, and remove key.**


**FOR SAFETY: When servicing machine, block machine tires before jacking machine up. Use a hoist or jack that will support the weight of the machine. Jack machine up at designated locations only. Support machine with jack stands.**

The front jacking locations are the flat bottom edge of the machine frame next to the front tires.



08586

The rear jacking location is the middle of the rear bumper.



08485

### STORAGE INFORMATION

The following steps should be taken prior to storing the machine for extended periods.

1. Park the machine in a cool, dry area. Do not expose the machine to rain or snow. Store indoors.
2. Remove the battery, or charge battery every three months.

Before storing the machine for an extended period of time, the machine needs to be prepped to lessen the chance of rust, sludge, and other undesirable deposits from forming. Contact TENNANT service personnel.



**SPECIFICATIONS**
**GENERAL MACHINE DIMENSIONS/CAPACITIES**

| Item                                        | Dimension/capacity              |
|---------------------------------------------|---------------------------------|
| Length                                      | 3050 mm (120 in)                |
| Width                                       | 1780 mm (70 in)                 |
| Height (top of air cleaner)                 | 1875 mm (73.8 in)               |
| Height with overhead guard                  | 2095 mm (82.5 in)               |
| Height with overhead guard and hazard light | 2310 mm (91 in)                 |
| Height with cab                             | 2095 mm (82.5 in)               |
| Height with cab & air conditioner           | 2257 mm (89 in)                 |
| Height with cab and hazard light            | 2310 mm (91 in)                 |
| Track                                       | 1560 mm (61.5 in)               |
| Wheelbase                                   | 1420 mm (56 in)                 |
| Main brush diameter                         | 405 mm (16 in)                  |
| Main brush length                           | 1270 mm (50 in)                 |
| Power Throw brush diameter                  | 205 mm (8 in)                   |
| Power Throw brush length                    | 1170 mm (46 in)                 |
| Side brush diameter                         | 65 mm (26 in)                   |
| Sweeping path width                         | 1270 mm (50 in)                 |
| Sweeping path width with side brush         | 1675 mm (66 in)                 |
| Sweeping path width with dual side brushes  | 2100 mm (82 in)                 |
| Main brush pattern width                    | 50 to 65 mm (2.0 to 2.5 in)     |
| Hopper weight capacity                      | 907.2 kg (2000 lb)              |
| Hopper volume capacity                      | 849.5 L (30 cu ft)              |
| Dust filter area                            | 17.7 m <sup>2</sup> (190 sq ft) |
| GVWR                                        | 4068 kg (8970 lb)               |
| Ceiling height minimum dumping clearance    | 3355 mm (11 ft)                 |
| Protection Grade                            | IPX3                            |

| Values determined as per IEC 60335- 2- 72         | Measure               |
|---------------------------------------------------|-----------------------|
| Sound pressure level $L_{pA}$                     | 83 dB(A)              |
| Sound uncertainty $K_{pA}$                        | 3 dB(A)               |
| Sound power level $L_{WA}$ + Uncertainty $K_{WA}$ | 103 dB(A)             |
| Vibration - Hand- arm                             | <2.5 m/s <sup>2</sup> |
| Vibration - Whole body                            | <0.5 m/s <sup>2</sup> |

## SPECIFICATIONS

### GENERAL MACHINE PERFORMANCE

| Item                                                    | Measure           |
|---------------------------------------------------------|-------------------|
| Maximum forward speed                                   | 16 kmh (10 mph)   |
| Maximum reverse speed                                   | 7.3 kmh (4.5 mph) |
| Minimum aisle turn width, left                          | 3450 mm (135 in)  |
| Minimum aisle turn width, right                         | 4675 mm (184 in)  |
| Maximum rated climb and descent angle (Sweeping)        | 15%               |
| Maximum rated climb and descent angle with empty hopper | 27%               |
| Maximum ambient temperature for machine operation       | 43° C (110° F)    |
| Minimum ambient temperature for machine operation       | 0° C (32° F)      |

### POWER TYPE

| Engine                                                                     | Type                                            | Ignition | Cycle                               | Aspiration | Cylinders | Bore                                      | Stroke                |
|----------------------------------------------------------------------------|-------------------------------------------------|----------|-------------------------------------|------------|-----------|-------------------------------------------|-----------------------|
| Kubota 4i V2403                                                            | Piston                                          | Diesel   | 4                                   | Turbo      | 4         | 87 mm<br>(3.43 in)                        | 102.4 mm<br>(4.04 in) |
|                                                                            | Displacement                                    |          | Tennant governed power              |            |           | Gross intermittent<br>power per SAE J1995 |                       |
|                                                                            | 2.434 L. (148 cu in)                            |          | 41.0 kw (55 hp) @ 2400 rpm          |            |           | 41.7 kw (55.9 hp) @<br>2600 rpm           |                       |
|                                                                            | Fuel                                            |          | Cooling system                      |            |           | Electrical system                         |                       |
|                                                                            | Low Sulfur Diesel<br>Fuel tank: 45.5 L (12 gal) |          | Water/ethylene glycol<br>antifreeze |            |           | 12 V nominal                              |                       |
|                                                                            |                                                 |          | Total: 13.6 L (3.6 gal)             |            |           | 90 A alternator (std)                     |                       |
|                                                                            |                                                 |          | Radiator: 6.2 L (1.6 gal)           |            |           |                                           |                       |
|                                                                            | Idle speed, no load                             |          | Intermediate speed, under load      |            |           | Governed speed,<br>under load             |                       |
|                                                                            | 1350 ± 50 rpm                                   |          | 2000 ± 50 rpm                       |            |           | 2400 ± 50 rpm                             |                       |
|                                                                            | Engine lubricating oil with filter              |          |                                     |            |           |                                           |                       |
| 5.7 L (6 qt) with remote filter, API diesel classification CJ- 4 or better |                                                 |          |                                     |            |           |                                           |                       |

### STEERING

| Type                                                       | Power source             | Emergency steering |
|------------------------------------------------------------|--------------------------|--------------------|
| Rear wheel, hydraulic cylinder and rotary valve controlled | Hydraulic accessory pump | Manual             |

### HYDRAULIC SYSTEM


| System              | Capacity          | Fluid Type                                                              |
|---------------------|-------------------|-------------------------------------------------------------------------|
| Hydraulic reservoir | 47.3 L (12.5 gal) | ISO Grade 100 - above 7° C (45° F)<br>ISO Grade 32 - below 7° C (45° F) |
| Hydraulic total     | 56.8 L (15 gal)   |                                                                         |

**BRAKING SYSTEM**


| Type           | Operation                                                                            |
|----------------|--------------------------------------------------------------------------------------|
| Service brakes | Hydraulic drum brakes (2), one per front wheel, foot brake master cylinder activated |
| Parking brake  | Utilize service brakes, cable actuated                                               |

**TIRES**


| Location  | Type      | Size          | Pressure                      |
|-----------|-----------|---------------|-------------------------------|
| Front (2) | Pneumatic | 6.5 x 23.5 in | 690 - 758 kPa (100 - 110 psi) |
| Rear (1)  | Pneumatic | 6.5 x 23.5 in | 690 - 758 kPa (100 - 110 psi) |



**TOP VIEW**



**SIDE VIEW**



**FRONT VIEW**

**MACHINE DIMENSIONS**

08774

